


2. Check the software version that is currently installed on the camera (System – IP Camera Maintain – Software Version)




3. [Click here](#) to download NC323XD firmware files
4. Extract files from zip and copy "**NC323XD_NC531XB_NC512XC_NC512XD_NC528XC_V21.45.7.1_211123**" folder to USB flash drive
5. Connect USB to NVR and watch youtube video demonstrating how to perform the upgrade - <https://www.youtube.com/watch?v=nNoH4Fu11qM>
6. If the software version (as inspected in step 2) is v21.45.7.0_210430 then upgrade to: V21.45.7.1_211123 using **NC323XD_F128M_SF_ENU_IVSEC_V21.45.7.1_211123_r10728_W.sw.**
Wait approx. 3 minutes for FW to update


NOTE: If existing camera software version is V21.45.7.1_211112 you can either perform an online update (as shown in YouTube video from 2:00 - 2:55) or manually upgrade using firmware file **NC323XD_F128M_SF_ENU_IVSEC_V21.45.7.1_211123_r10728_W.sw.**

- Once cameras restart and come back online verify V21.45.7.1_211123 is now listed as the camera software version and default the cameras to confirm all settings take effect. (Refer to YouTube video from 4:08 - 4:50)

System – IP Camera Maintain – Load Default – Tick Cameras, Click “Load Default”. You will be required to enter your NVR password for authentication



- For any future camera firmware updates, you will be able to perform an online update by Click system – IP Camera Maintain – Tick the camera and click Detect. If a new firmware version is available a popup message will appear



If you require additional support, please email service@ivsecurity.com.au with your NVR model, serial number, a brief description of the issue and your contact details.